

PARAMOUNT RESOURCES LTD.

DAILY DRILLING REPORT

WELL NAME - PARA et al MOUNT COTY
UNIQUE I.D. 60-11 & 123-30

LOCATION: 1-02
WELL LICENCE WID - 1884

SUPERVISOR: Wilbert Cellihoo
CELLULAR #: 1-780-940-8855
SPUD DATE: 10 - 18 - 2000 - 22:00 Hrs.
R.R. DATE: _____
CONTRACTOR: AKITA DRLG - RIG #51
A.F.E. #: 00N010052 **EST. T.D** 1800M

DAILY COST: \$59,000
CUM. COST: \$4,478,000
DAILY MUD: \$600
CUM MUD: \$54,800

DAY: 48 **REP DATE:** 12/4/00 **STATUS** 08:00 Circ 177.8 mm Casing on Bottom
DEPTH: 1744 **PROG.** _____ **KB:** 5.05M 367.90M **MACP:** 2872
SURVEYS: _____

MUD TYPE: GEL-CHEM **WT** 1270 **VISC:** 64 **WL** 7 **FC** 2 10
ADDITIVES: 1 Sack Caustic - 1 Sack Soda Ash - 5 Sax Sawdust - 20 Sax Barite

BIT	SERIAL #	SIZE	MFG	TYPE	JETS	OUT	RUN	HRS	TBG	WEIGHT	RPM
RR23	LY4872	222mm	Smith	F-47H	3x10.3	1744		Circ	on	Bottom	

PUMP	DESCR.	LINER	STK	SPM	RATE	PRESS	AV DC	AV DP	NOZZEL VEL
National	8P-80	152mm	216mm	90	1.060	78000	54	42	68
National	8P-80	152mm	216mm						

DRILLING ASSEMBLY

TOOL	OD	ID	LENGTH
BIT & DOG SUB	222mm		0.50
BIT SUB	172mm	73	0.86
6-DRILL COLLARS	172	73	55.64
DRLG JARS	172	58	6.06
X/O SUB	172	73	0.76
40-HEVI-WATE DP	114	92	367.64
177 DRILL PIPE	114	101	1300.10
KELLY	114	82	12.44
TOTAL			1744.00

TIME DISTRIBUTION

MOVE/RIG-UP	_____	RIG REP:	_____
DRILL MH & RH:	_____	LOGGING:	_____
RIG SERVICE:	<u>0.25</u>	CEMENT:	_____
SURVEY:	_____	WOC:	_____
PRESSURE TEST:	_____	RUN CSG:	<u>3.25</u>
DRILL:	_____	DST:	<u>0.50</u>
DRILL OUT:	_____	TRIP:	<u>13.50</u>
CIRCULATE:	<u>8.25</u>	FISHING	_____
NIPPLE UP BOP:	_____	REAM:	_____
MIX LCM	_____	DRILLLINE	_____
Safety MTGS	<u>0.25</u>		
TOTAL HOURS:	<u>24.00</u>		

CASING SUMMARY

RAN _____ JTS OF _____ MM, _____ KGM, _____ CABING.
 LANDED AT _____ MKB. **TOTAL LENGTH** _____ METERS.

**CEMENTED WITH
 PLUG DOWN AT**

_____ HRS. ON _____ WITH _____ M3 CEMENT RETURNS.

Finish Laying Down and Loading out Test Tools - Released Testers - Make up Bit and Dog Sub - Run in Hole - Break Circ and Circ @ 1250M - Finish Running in Hole to Bottom - Break Circ and Circ on Bottom - Work Pipe while Circ to Condition Mud and Hole for Laying Down Pipe and Running Casing - Pump Wt Mat Pill - Pull out of Hole Laying Down Drill Pipe - Hevi-Wate Pipe and Drill Collars - Measure Casing on Rack and Rig to Run Casing - Running Casing @ Midnite and Have Casing on Bottom and Circ at Report Time - Will Rig in Cementers and Cement Casing.
 Weather This A.M. - Clear - S.W. Wind @ 15 Km/h - Cold - Temp -22oC.